



NOTE:
 HARDWARE KIT THAT IS INCLUDED WITH THE DISPLAY
 COMES WITH A GASKET. THE GASKET NEEDS TO BE
 USED BETWEEN THE DISPLAY AND PANEL.

USE THIS TEMPLATE FOR
 STANDARD THROUGH THE
 DASH INSTALATION

70591 R1