

**24V - 12V  
DROPPING RESISTOR  
INSTRUCTIONS**

THE FOLLOWING ARE INSTRUCTIONS FOR INSTALLING A 24V - 12V DROPPING RESISTOR. IT'S USE IS RESTRICTED TO 24 VOLT NEGATIVE GROUND ELECTRICAL SYSTEMS. IT IS COMPATIBLE WITH GAUGES MANUFACTURED BY VEETHREE, INC. (USA).

Additional equipment needed to complete installation:

- Insulated terminal lugs as required

**CAUTION:**


**READ AND FOLLOW THESE INSTRUCTIONS CAREFULLY BEFORE PROCEEDING WITH INSTALLATION. DO NOT DEVIATE FROM WIRING INSTRUCTIONS. INCORRECT INSTALLATION COULD CAUSE ELECTRICAL SHORT WITH POSSIBLE FIRE. ALWAYS DISCONNECT BATTERY BEFORE MAKING ANY ELECTRICAL CONNECTIONS.**

**CONNECTION OF WIRING**

1. Connect ring terminal of Dropping Resistor to "I" or "IGN" (ignition) terminal of desired gauge.
2. Connect female blade terminal of Dropping Resistor to 24V lead incoming from battery.

**CAUTION**

**BEFORE RECONNECTING BATTERY TO ELECTRICAL SYSTEM, RECHECK WIRING TO INSURE ALL CONNECTIONS ARE PROPERLY MADE. INCORRECT CONNECTIONS OR ELECTRICAL SHORTS COULD CAUSE DAMAGE TO GAUGE OR FIRE IN SYSTEM. ELEMENTS OF ELECTRICAL SYSTEMS SHOULD HAVE PROPER FUSES INSTALLED.**



USA Sales/Support  
Veethree Electronics and Marine  
2050 47th Terrace East  
Bradenton, FL 34203 USA  
Tel 941-538-7775  
Fax 941-775-1222  
techservice@veethree.com  
www.veethree.com

**24V - 12V  
DROPPING RESISTOR  
INSTRUCTIONS**

THE FOLLOWING ARE INSTRUCTIONS FOR INSTALLING A 24V - 12V DROPPING RESISTOR. IT'S USE IS RESTRICTED TO 24 VOLT NEGATIVE GROUND ELECTRICAL SYSTEMS. IT IS COMPATIBLE WITH GAUGES MANUFACTURED BY VEETHREE, INC. (USA).

Additional equipment needed to complete installation:

- Insulated terminal lugs as required

**CAUTION:**


**READ AND FOLLOW THESE INSTRUCTIONS CAREFULLY BEFORE PROCEEDING WITH INSTALLATION. DO NOT DEVIATE FROM WIRING INSTRUCTIONS. INCORRECT INSTALLATION COULD CAUSE ELECTRICAL SHORT WITH POSSIBLE FIRE. ALWAYS DISCONNECT BATTERY BEFORE MAKING ANY ELECTRICAL CONNECTIONS.**

**CONNECTION OF WIRING**

1. Connect ring terminal of Dropping Resistor to "I" or "IGN" (ignition) terminal of desired gauge.
2. Connect female blade terminal of Dropping Resistor to 24V lead incoming from battery.

**CAUTION**

**BEFORE RECONNECTING BATTERY TO ELECTRICAL SYSTEM, RECHECK WIRING TO INSURE ALL CONNECTIONS ARE PROPERLY MADE. INCORRECT CONNECTIONS OR ELECTRICAL SHORTS COULD CAUSE DAMAGE TO GAUGE OR FIRE IN SYSTEM. ELEMENTS OF ELECTRICAL SYSTEMS SHOULD HAVE PROPER FUSES INSTALLED.**



USA Sales/Support  
Veethree Electronics and Marine  
2050 47th Terrace East  
Bradenton, FL 34203 USA  
Tel 941-538-7775  
Fax 941-775-1222  
techservice@veethree.com  
www.veethree.com